Intrduction



 Copyright 2007 J.E. Akin. All rights reserved.

Adding an implant loading area













 Copyright 2007 J.E. Akin. All rights reserved.

Add the cement layer









 Copyright 2007 J.E. Akin. All rights reserved.



Add a mating bone solid

 Copyright 2007 J.E. Akin. All rights reserved.



 Copyright 2007 J.E. Akin. All rights reserved.



Prepare to remove the cement volume from the bone





 Copyright 2007 J.E. Akin. All rights reserved.





 Copyright 2007 J.E. Akin. All rights reserved.



Build an assembly for stress analysis



 Copyright 2007 J.E. Akin. All rights reserved.





Mate the cement to the bone





 Copyright 2007 J.E. Akin. All rights reserved.



images out of order here (missing)

two more mates









Add the implant solid to the assembly

 Copyright 2007 J.E. Akin. All rights reserved.



 Copyright 2007 J.E. Akin. All rights reserved.



Conduct stress analysis of assembly



Set each of the three material region properties

 Copyright 2007 J.E. Akin. All rights reserved.







 Copyright 2007 J.E. Akin. All rights reserved.





 Copyright 2007 J.E. Akin. All rights reserved.



Now set (assumed) loads and restraints

(The touching material interfaces are automatically bonded.)



 Copyright 2007 J.E. Akin. All rights reserved.





 Copyright 2007 J.E. Akin. All rights reserved.



 Copyright 2007 J.E. Akin. All rights reserved.

Build a mesh



Run the model solution

 Copyright 2007 J.E. Akin. All rights reserved.





Plot the displaqcements





 Copyright 2007 J.E. Akin. All rights reserved.



Examine Stresses



 Copyright 2007 J.E. Akin. All rights reserved.





 Copyright 2007 J.E. Akin. All rights reserved.



 Copyright 2007 J.E. Akin. All rights reserved.





 Copyright 2007 J.E. Akin. All rights reserved.

Plot the intensity (twice the max shear stress)



 Copyright 2007 J.E. Akin. All rights reserved.